

KEYENCE BT-A700G - Scanner Parameters

Purpose

This guide describes the required scanner settings on the KEYENCE BT-A700G so that COBI.wms can correctly recognize and process barcodes (e.g., EAN/UPC, Code128, EAN128/GS1). Key points:

* Enable **AIM ID Prefix** (reliable barcode type identification) * Configure **Data Output** correctly (KeyEvent + Intent/Broadcast) * Set **Intent extras (Code type / Raw data / Data)** (proper handover to COBI.wms)

—

Step-by-step instructions

1) Open Android Settings (Fig. 1)

1. Open the **app overview** (home screen / list of all apps). 2. Tap **Settings**.

2) Open Scanner Settings (Fig. 2)

1. In Android Settings, select **Scanner** (scan parameters, code settings).

3) Open Data Formatting (Fig. 3)

1. In the **Scanner** menu, scroll to the **Data** section. 2. Open **Data formatting**.

4) Enable "AIM ID Prefix" (Fig. 4)

1. Enable **AIM ID Prefix** (check the box).

Why this matters: The AIM ID adds an identifier to the scanned data so COBI.wms can reliably determine the **barcode type** (e.g., GS1/EAN128 vs. Code128). This is especially important for GS1 logic (AI structures).

5) Go back and open "Data Output" (Fig. 5)

1. Go **one step back** to the Scanner menu. 2. Open **Data output**.

6) Set Transmission Type to "KeyEvent" (Fig. 6)

1. Under **Transmission type**, set the value to **KeyEvent**.

Short note: "KeyEvent" sends scanned data as keyboard/event input (keystrokes), improving compatibility and handling of special characters/structures in input fields.

7) Enable Intent and configure Broadcast (Fig. 7)

1. In **Data output**, tap **Intent**. 2. Enable **Intent** (check the box). 3. Under **Action**, enter this value exactly:

- ``de.cobi.wms.action.DATAWEDGE_BARCODE``

4. Set the **Transmission type** in the Intent section to:

- **Broadcast**

Why this matters: COBI.wms expects scan data via a defined Intent action. Using **Broadcast** ensures the scan Intent is delivered to the app so the correct internal logic is triggered.

8) Set Intent extras: Code type / Raw data / Data (Fig. 8)

Scroll further down in the Intent settings and set these values **manually**:

* **Code type** → `com.motorolasolutions.emdk.datawedge.label_type` * **Raw data** →
`com.motorolasolutions.emdk.datawedge.source` * **Data** →
`com.motorolasolutions.emdk.datawedge.data_string`

These extras ensure COBI.wms receives the information in the expected structure and can process the barcode logic correctly (including type/source/payload).

—

Final step: Restart the app

1. **Fully close COBI.wms** (remove it from the recent apps list / swipe it away). 2. **Open COBI.wms again**. 3. Start scanning and validate the result.

—

Troubleshooting / Support

If issues persist:

1. Re-check all settings (especially **AIM ID, KeyEvent, Intent + Action, Broadcast, Extras**). 2. Reboot the device and test again. 3. If the problem still occurs, please send:

- the **exact workflow** (module, input field, what you scan),
- **screenshots** of the settings,
- the **affected barcodes** (sample data)

to: [\[support@cobisoft.de\]\(mailto:support@cobisoft.de\)](mailto:support@cobisoft.de).

From:
<https://docs.cobisoft.de/wiki/> - **COBISOFT Documentation**

Permanent link:
https://docs.cobisoft.de/wiki/cobl.wms/keyence_settings?rev=1765543652

Last update: **2025/12/12 13:47**

